# 06ex Pandas

January 19, 2025

# 1 Just one (long) exercise: TDC signals analysis (done)

### 1.0.1 Description

This exercise consists in analyzing a dataset containg timing information from a series of Time-to-Digital-Converters (TDC), implemented in a couple of FPGAs. Each measurement (i.e. each row of the input file) consists of: - a flag that specifies the type of message ('HEAD', which in this case is always 1), - two addresses of the TDC providing the signal ('FPGA' and 'TDC\_CHANNEL') - the timing information ('ORBIT\_CNT', 'BX\_COUNTER', and 'TDC\_MEAS').

The triplet ('ORBIT\_CNT', 'BX\_COUNTER', and 'TDC\_MEAS') is a format for the time information as - Each TDC count corresponds to 25/30 ns (\*\*/ means division\*\*),

- Each BX\_COUNTER corresponds to 25 ns,
- the ORBIT\_CNT is increased every 'x' BX\_COUNTER (with the value of x to be found)

This allows to store the time in a similar way to hours, minutes and seconds.

#### 1.0.2 Requests

- 1. Create a Pandas DataFrame reading N rows of the 'data\_000637.txt' dataset. Choose N to be smaller than or equal to the maximum number of rows and larger that 10k.
- 2. Find out the number of BX in a ORBIT (the value 'x').
- 3. Find out how much the data taking lasted. You can either make an estimate based on the fraction of the measurements (rows) you read, or perform this check precisely by reading out the whole dataset.
- 4. Create a new column with the absolute time in ns (as a combination of the other three columns with timing information).
- 5. Replace the values (all 1) of the HEAD column randomly with 0 or 1.
- 6. Create a new DataFrame that contains only the rows with HEAD=1.
- 7. Make two occupancy plots (one for each FPGA), i.e. plot the number of counts per TDC channel
- 8. Use the groupby method to find out the noisy channels, i.e. the TDC channels with most counts (say the top 3)
- 9. Count the number of unique orbits. Count the number of unique orbits with at least one measurement from TDC CHANNEL=139

#### 1.0.3 Solution

```
[1]: # -L option: follow the redirection link to the actual file
     #!curl -L -O https://www.dropbox.com/s/xvjzaxzz3ysphme/data_000637.txt
     import csv
     import pandas as pd
     import numpy as np
     import matplotlib.pyplot as plt
[2]: filename = "data_000637.txt"
     # inspect how many rows are there in the file
     with open(filename, mode= 'r', ) as f:
        reader = csv.reader(f, delimiter=',') # Specify ',' as the delimiter
         # print first 5 row to ensure everything is ok
        for i, row in enumerate(reader):
            print(row)
             if i == 5:
                 break
         # now count the rows
        nrows = sum(1 for _ in reader)
     f.close()
     print(f"number of rows in the file: {nrows}")
    ['HEAD', 'FPGA', 'TDC_CHANNEL', 'ORBIT_CNT', 'BX_COUNTER', 'TDC_MEAS']
    ['1', '0', '123', '3869200167', '2374', '26']
    ['1', '0', '124', '3869200167', '2374', '27']
    ['1', '0', '63', '3869200167', '2553', '28']
    ['1', '0', '64', '3869200167', '2558', '19']
    ['1', '0', '64', '3869200167', '2760', '25']
    number of rows in the file: 1310715
[3]: N = np.power(10, 6)
     df = pd.read_csv(filepath_or_buffer= filename, nrows= (N + 1))
     # nrows : int, optional. Number of rows of file to read. Useful for reading
     ⇔pieces of large files
     df.tail(20)
[3]:
             HEAD FPGA TDC_CHANNEL
                                      ORBIT_CNT BX_COUNTER
                                                              TDC_MEAS
     999981
                1
                      0
                                  124 3869209011
                                                         2539
                                                                     11
    999982
                1
                      0
                                   61 3869209011
                                                         2527
                                                                      7
    999983
                1
                      1
                                   5 3869209011
                                                         2544
                                                                     25
                1
                      0
     999984
                                 124 3869209011
                                                         2544
                                                                     12
    999985
                1
                      0
                                   64 3869209011
                                                         2531
                                                                     23
                1
                     1
    999986
                                  7 3869209011
                                                         2546
                                                                     13
    999987
                      0
                                  60 3869209011
                                                         2554
                                                                      2
```

999988	1	1	139	3869209011	2553	0
999989	1	1	4	3869209011	2551	14
999990	1	0	121	3869209011	2554	24
999991	1	0	59	3869209011	2558	9
999992	1	0	49	3869209011	2557	3
999993	1	0	123	3869209011	2553	13
999994	1	0	60	3869209011	2561	27
999995	1	0	62	3869209011	2560	29
999996	1	0	51	3869209011	2561	12
999997	1	0	61	3869209011	2562	2
999998	1	0	50	3869209011	2563	4
999999	1	0	60	3869209011	2688	25
1000000	1	1	57	3869209011	2849	13

Comment: I see that the BX\_COUNTER values are not monotonically increasing. Maybe the measures (the rows) are not chronologically ordered, or maybe it is impossible to find their chronological ordering exactly because the timing values are affected by statistical errors.

### 2. I need to find the range of TCD\_MEAS and BX\_COUNTER.

For the time format ("hours", "minutes", "seconds") I know that "minutes" ranges from 0 to 60 and then resets. I want to get the same information about this other time format. There are two ways I can do this:

- use np.max(), np.min()
- plot the whole distribution and get its extrema


The second approach is smarter, since I can verify that the values returned by np.max() and np.min() are the actual extrema of a continuous range and not - for instance - some outlier, wrong value. Also, I can check if the times of the measures are uniformly distributed or not. If not, and I know that the physical process is random and uncorrelated, there might be some systematic error in the measurement system.

To do it I use statistics: the dataset is very large (one million measures), and I expect the sampling times to be a uniform random variable. Hence, if I plot the histogram of TDC\_MEAS, I expect to find the whole range of values.

```
[4]: fig, axs = plt.subplots(nrows = 1, ncols = 2)
    plt.subplots_adjust(wspace= 0.5)
    axs[0].hist(df['TDC_MEAS'])
    axs[0].set_title('TDC_MEAS')
    axs[1].hist(df['BX_COUNTER'])
    axs[1].set_title('BX_COUNTER')
    tcd_min, tcd_max = df['TDC_MEAS'].min(), df['TDC_MEAS'].max()
    print(tcd_min, tcd_max)

bx_counter_min, bx_counter_max = df['BX_COUNTER'].min(), df['BX_COUNTER'].max()
    print(bx_counter_min, bx_counter_max)
```

0 29 0 3563



Summary: TCD\_MEAS resets at 30 and BX counter resests at 3563: there are x=3564 BX\_COUNTER units in a ORBIT\_CNT

ORBIT\_CNT::BX\_COUNTER::TCD\_MEAS [0, ..]::[0, 3563]::[0, 29]

# 1.0.4 Request 3

Find out how much the data taking lasted. You can either make an estimate based on the fraction of the measurements (rows) you read, or perform this check precisely by reading out the whole dataset.

```
[5]: #df['ORBIT_CNT'].hist(bins = 10)
orbs_count_min = np.min(df['ORBIT_CNT'])
orbs_count_max = np.max(df['ORBIT_CNT'])
num_orbs_counts = orbs_count_max - orbs_count_min + 1
num_orbs_counts
```

[5]: np.int64(8845)

```
[6]: tdc_in_ns = 25./30
bx_in_ns = 25
# Check:
#print(tdc_in_seconds * (tcd_max+ 1), bx_in_seconds) perfect, it agrees

orbs_in_ns = bx_in_ns * (bx_counter_max + 1)
#print(orbs_count_in_seconds)
subset_total_time = num_orbs_counts * orbs_in_ns
total_time = (subset_total_time/ N) * nrows

print("Total measurement time (estimated):", total_time, " ns")
```

Total measurement time (estimated): 1032960728.9925001 ns

**4.** Create a new column with the absolute time in ns (as a combination of the other three columns with timing information).

5. Replace the values (all 1) of the HEAD column randomly with 0 or 1.

```
[8]: import numpy.random as npr
df['HEAD'] = npr.choice([0, 1], size= len(df))
#df.head()
```

**6.** Create a new DataFrame that contains only the rows with HEAD=1.

```
[9]: df_filtered = df[df["HEAD"] == 1].reset_index(drop= True)#.copy() it is<sub>□</sub>

⇔superfluous

print(df_filtered.head())
```

```
HEAD
         FPGA
              TDC_CHANNEL
                             ORBIT_CNT BX_COUNTER TDC_MEAS
                                                                     time_ns
0
      1
                       123 3869200167
                                               2374
                                                                59371.666667
            0
                                                            26
                                               2374
1
      1
            0
                       124
                            3869200167
                                                            27
                                                                59372.500000
2
      1
            0
                        63
                            3869200167
                                               2553
                                                            28
                                                                63848.333333
3
      1
            0
                        64 3869200167
                                               2558
                                                            19
                                                                63965.833333
4
      1
                        64 3869200167
                                               2760
                                                            25 69020.833333
            0
```


7. Make two occupancy plots (one for each FPGA), i.e. plot the number of counts per TDC channel

```
[34]: # First try: groupby().count() (longer)
"""

df_ = df[['FPGA', 'TDC_CHANNEL']].copy()

df_['COUNTS'] = pd.Series(np.ones(len(df)))
result = df_.groupby(['FPGA', 'TDC_CHANNEL']).count()
```

```
result_flattened = result.reset_index()
fig, ax = plt.subplots()
for fpga in np.unique(result_flattened['FPGA']):
    temp_df = result_flattened[result_flattened['FPGA'] == fpga]
    x, y = temp_df['TDC_CHANNEL'].values, temp_df['COUNTS'].values
    ax.bar(x, y, label = fpga)
ax.legend(title= "FPGA")
ax.set_xlabel('TDC_CHANNEL')
ax.set_ylabel('COUNTS')
ax.set_title("Occupacy Plot")
# Second try: groupby().size() (best)
for fpga in [0, 1]:
    result = df.groupby(['FPGA', 'TDC_CHANNEL']).size()
    \#result.xs(fpga, level = 'FPGA') \# multi-index accessing: access all rows_{\sqcup}
 ⇔where the index "FPGA" is 1
    plt.bar(x = result.xs(fpga, level= 'FPGA').index, height= result.xs(fpga, |
 ⇔level= 'FPGA').values, align= 'edge')
```



#### 1.0.5 8.

Use the groupby method to find out the noisy channels, i.e. the TDC channels with most counts (say the top 3)

```
[19]: # I sum the counts coming from FPGA 0 and FPGA 1.

# First method (longer)
#df_ = df[['TDC_CHANNEL']].copy()
#df_ ['COUNTS'] = pd.Series(np.ones(len(df_)))
#result = df_.groupby(['TDC_CHANNEL']).count()
#result.sort_values(by= 'COUNTS', ascending= False)
#result

# Second method (optimized)
result = df.groupby(['TDC_CHANNEL']).size().sort_values(ascending=False)
result
```

```
[19]: TDC_CHANNEL
      139
              82677
      64
              50201
      63
              49335
      61
              37789
      62
              37602
      125
                457
      130
                 53
      138
                 52
      137
                 50
      129
                 28
      Length: 133, dtype: int64
```

## 2 9.

- Count the number of unique orbits.
- $\bullet$  Count the number of unique orbits with at least one measurement from TDC\_CHANNEL=139

unique\_orbits: 8841

```
[45]: ORBIT_CNT
                  TDC_CHANNEL
      3869200167 5
                                   1
                  6
                                   1
                  7
                                   1
                                   1
                  8
                  10
                                   1
                                  . .
      3869209011 109
                                   1
                  121
                                   1
                  123
                                   1
                  124
                                   2
                  139
                                  12
      Length: 440984, dtype: int64
[48]: pd_series = result.xs(139, level= 'TDC_CHANNEL')
      print(pd_series)
      unique_orbits_with_139_counts = len(pd_series.index)
      unique_orbits_with_139_counts
     ORBIT_CNT
                     4
     3869200167
     3869200168
                     8
     3869200169
                   11
                     9
     3869200170
                     9
     3869200171
                    . .
     3869209007
                   10
                   22
     3869209008
     3869209009
                   15
                    7
     3869209010
     3869209011
                    12
     Length: 8816, dtype: int64
[48]: 8816
```